# Remote control configuration for VCR/DVD

This remote control is default to operate basic functions of this Sony TV, Sony DVD and most of Sony VCR when batteries are initially installed. To control other VCR and DVD major brands and some Sony VCR models, please complete the following steps:

- Before you start, look up the 3 digit code for your brand of DVD or VCR from the list below. On those brands that have more than one code, enter the first code number.
- Sony will endeavour to update the software according to market changes. Therefore, please refer to code table included with the remote control for latest code set.

**1** Press the Media Selector button on the remote control repeatedly until the required VCR or DVD green light is lit.

If Media Selector is on TV position, code numbers will not be sotred.

**2** Before the green light goes out, press and hold the yellow button for approximately 6 seconds until the green light starts flashing.

**3** Whilst the green light is flashing, enter all three digits of the code for your brand using the number buttons on the remote control.

If your selected code is entered correctly, all three green lights will be lit momentarily.

**4** Turn on your brand VCR or DVD and check that the main functions work.

- If your device is not working or some of the functions do not work please check you entered the correct code set or try the next code listed against the brand.
- Your brand codes may be lost if weak batteries are not replaced within a few minutes. To reset your brand DVD or VCR please repeat the above steps. A small label is added inside the battery door to allow you to record your brand codes.
- Not all brands are covered and not all models of every brand may be covered.

## VCR Brand List

| Brand | Code |
|---|---|
| SONY (VHS) | 301, 302, 303, 308, 309 |
| SONY (BETA) | 303, 307, 310 |
| SONY (DV) | 304, 305, 306 |
| AIWA | 325, 331, 351 |
| AKAI | 326, 329, 330 |
| DAEWOO | 342, 343 |
| GRUNDIG | 358, 355, 360, 361, 320, 351 |
| HITACHI | 327, 333, 334 |
| JVC | 314, 315, 322, 344, 352, 353, 354, 348, 349 |
| LG | 332, 338 |
| LOEWE | 358, 355, 360, 361, 320, 351 |
| MATSUI | 356, 357 |
| ORION | 328 |
| PANASONIC | 321, 323 |
| PHILIPS | 311, 312, 313, 316, 317, 318, 358, 359 |
| SAMSUNG | 339, 340, 341, 345 |
| SANYO | 335, 336 |
| SHARP | 324 |
| THOMSON | 319, 350 |
| TOSHIBA | 337 |

## DVD Brand List

| Brand | Code |
|---|---|
| SONY | 001 |
| AIWA | 021 |
| DENON | 018, 027, 020, 002 |
| GRUNDIG | 009, 028, 023, 024, 016, 003 |
| HITACHI | 025, 026, 015, 004 |
| JVC | 006, 017 |
| KENWOOD | 008 |
| LG | 015, 014 |
| LOEWE | 009, 028, 023, 024, 016, 003 |
| MATSUI | 013, 016 |
| ONKYO | 022 |
| PANASONIC | 018, 027, 020, 002 |
| PHILIPS | 009, 028, 023, 024, 016, 003 |
| PIONEER | 004 |
| SAMSUNG | 011, 014 |
| SANYO | 007 |
| SHARP | 019, 027 |
| THOMSON | 012 |
| TOSHIBA | 003 |
| YAMAHA | 018, 027, 020, 002 |